



Kreidler Supermoto 125 DD Oil Change

In this tutorial you will learn hoe to change the oil and filter of a kreidler supermoto 125 DD.

Written By: Ismael Domingos

INTRODUCTION

In this tutorial you will learn hoe to change the oil and filter of a kreidler supermoto 125 DD.

Step 1 — Kreidler Supermoto 125 DD Oil Change



- First you need to remove the bottom screw located bellow the engine. And clean and save the two pieces that goes with it (spring and tip).

Step 2



- Then let all the oil drain from the reservoir.

Step 3



- Remove the cover of the oil filter and the filter itself.
- Drain all the remaining oil.

Step 4



- Clean the filter holding, place the new filter and screw tge cover in place.

Step 5



- Introduce the two pices and the bottom screw in their place with a new sealing ring in the right order (tip -> spring -> screw with sealing ring).

Step 6



- Remove the top lid of the cartrige and put the bike in a vertical position.
- Pour the new oil into the cartrige and monitor his level in the visor until it reaches the desired level.

Step 7



- Close the lid and start the engine to see if there are no leaks and to see if it is working smoothly.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 08:57:57 PM.